



smith+nobel



8LITRE DIGITAL AIR FRYER

Model No.: SN-KAF-8441

Instruction Manual

Read this instruction manual carefully before use and keep for future reference.

TABLE OF CONTENTS

IMPORTANT SAFEGUARDS

Parts & Accessories

Using the Control Panel

Instructions for Use

General Cooking Guidelines

Troubleshooting

Frequently Asked Questions

Cleaning & Storage

IMPORTANT SAFEGUARDS

WARNING

PREVENT INJURIES! – CAREFULLY READ ALL INSTRUCTIONS BEFORE USE!

When using electrical appliances, always follow these basic safety precautions.

1. **READ AND FOLLOW** all instructions carefully.
2. **NEVER** immerse the Main Unit Housing, which contains electrical components and heating elements, in water. Do not rinse under the tap.
3. **THIS APPLIANCE IS NOT INTENDED FOR** use by persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge unless they are under the supervision of a responsible person or have been given proper instruction in using the appliance. This appliance is not intended for use by children.
4. **TO AVOID ELECTRICAL SHOCK**, do not put liquid of any kind into the Main Unit Housing containing the electrical components.
5. **THIS APPLIANCE HAS A POLARIZED PLUG**
If it does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.
6. **MAKE SURE** the appliance is plugged into a wall socket. Always make sure that the plug is inserted into the wall socket properly.
7. **DO NOT** use outdoors.
8. **DO NOT** place the appliance on the stove top.
Place on a flat, horizontal surface with adequate space for air flow. Do not place other appliances within 15cm of the appliance.
9. **TO PREVENT** food contact with the heating elements, do not overfill.
10. **DO NOT** cover the Air Intake Vent or Hot Air Outlet Vent while the appliance is operating. Doing so will prevent even cooking and may damage the appliance or cause it to overheat.
11. **NEVER** pour oil into the Basket. Fire and personal injury could result.
12. **WHILE COOKING**, the internal temperature of the appliance reaches several hundred degrees. To avoid personal injury, never place hands inside the appliance unless it is thoroughly cooled down.
13. **DO NOT** use this appliance if the plug, the power cord, or the appliance itself is damaged in any way.
14. **IF THE POWER CORD IS DAMAGED**, you must have it replaced by the manufacturer, its service agent, or a similarly qualified person in order to avoid hazard.
15. **KEEP** the appliance and its power cord out of the reach of children when it is in operation or in the cooling down process.
16. **KEEP** the power cord away from hot surfaces. Do not plug in the power cord or operate the appliance controls with wet hands.
17. **NEVER** connect this appliance to an external timer switch or separate remote-control system.
18. **NEVER** use this appliance with an extension cord of any kind. A short power-supply cord (or detachable power-supply cord) is provided to reduce the risk of becoming entangled in or tripping over a longer cord.
19. **DO NOT** let cord hang over the edge of table or counter surfaces.
20. **DO NOT** operate the appliance on or near combustible materials, such as tablecloths, paper towels, or curtains.
21. **WHEN COOKING**, do not place the appliance against a wall or against other appliances. Leave at least 15cm. free space on the back and sides and above the appliance. Do not place anything on top of the appliance.
22. **DO NOT USE** the appliance for any purpose other than described in this manual.
23. **THE USE OF ACCESSORY ATTACHMENTS**
not recommended by the appliance manufacturer may cause injuries.
24. **NEVER** operate the appliance unattended.
25. **WHEN IN OPERATION**, hot air and steam is released through the Hot Air Outlet Vent. Keep your hands and face at a safe distance from the Hot Air Outlet Vent. Also avoid the hot steam and air while removing the Basket and Fry Tray from the appliance.
26. **THE APPLIANCE'S OUTER SURFACES** may become hot during use. The Basket and Fry Tray will be hot. Wear oven mitts when handling hot components or touching hot surfaces.
27. Before using your new appliance on any countertop surface, **CHECK** with your countertop manufacturer or installer for recommendations about using appliances on your surfaces. Some manufacturers and installers may

recommend protecting your surface by placing a hot pad or trivet under the appliance for heat protection. Your manufacturer or installer may recommend that hot pans, pots, or electrical appliances should not be used directly on top of the countertop. If you are unsure, place a trivet or hot pad under the appliance before using it.

28. The appliances are not intended to be operated by means of an external timer or separate remote-control system.
29. **DO NOT** place your appliance on a hot cooktop because it could cause a fire or damage the appliance, your cooktop, and your home.
30. **SHOULD THE APPLIANCE EMIT BLACK SMOKE**, unplug immediately and wait for smoking to stop. Allow the appliance to cool and wipe out excess oil and grease from the appliance.

31. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.

32. **USE EXTREME CAUTION** when removing tray or disposing of hot grease.

33. **DO NOT** clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating risks of electric shock.

34. This appliance is intended to be used in household and similar applications such as:

-staff kitchen areas in shops, offices and other working environments;

-farm houses;

-by clients in hotels, motels and other residential type environments; -bed and breakfast type environments.

SAVE THESE INSTRUCTIONS—FOR HOUSEHOLD USE ONLY



CAUTION

- Always operate the appliance on a horizontal surface that is level, stable, and noncombustible.
- This appliance is intended for normal household use only. It is not intended for use in commercial or retail environments.
- If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to the instructions in the user manual, the guarantee becomes invalid and the manufacturer will not be held liable for damages.
- Always unplug the appliance after use.
- When the cooking time has completed, cooking will stop and the fan will continue running for 10 seconds. to cool down the appliance.
- Let the appliance cool down for approximately 30 minutes. before handling, cleaning, or storing.
- The appliance is equipped with an internal microswitch that automatically shuts down the fan and heating element when the Basket is removed.

Overheating Protection

Should the inner temperature control system fail, the overheating protection system will be activated and the appliance will not function. Should this happen, unplug the appliance. Allow time for the appliance to cool completely before restarting or storing.

Automatic Shut-Off

The appliance has a built-in shut-off device that will automatically shut off the appliance when the cooking time has completed. You can manually switch off the appliance by pressing the Power Button. The fan will continue running for 10 seconds. to cool down the appliance.

Electric Power

The appliance should be operated on a dedicated electrical outlet. If the electrical outlet is being used by other appliances, your new Appliance may not operate properly.

Electromagnetic Fields

This appliance complies with all standards regarding electromagnetic fields. If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.


PARTS & ACCESSORIES



- 1. MAIN UNIT HOUSING
- 2. CONTROL PANEL
- 3. AIR INLET VENT
- 4. HOT AIR OUTLET VENT
- 5. POWER CABLE
- 6. BASKET
- 7. HANDLE
- 8. FRY TRAY
- 9. RUBBER BUMPERS*

NOTE: Unpack all listed contents from the packaging. Contents vary by model. Please remove any clear or blue protective film on the components before use.

*Removing bumpers is not recommended.




CAUTION: Appliance may be hot. Be careful not to touch the appliance while in use. Keep the appliance away from other objects.

IMPORTANT: Please make sure that your appliance has been shipped with the components that you ordered (some accessories may be sold separately). Check everything carefully before use. If any part is missing or damaged, contact customer service.

Technical Specifications

Model Number	Supply Power	Rated Power	Capacity	Temperature
SA-KAF8441	220-240V~ 50-60Hz	1800W	8 Litre	80°C–200°C



USING THE CONTROL PANEL

1. Power Button

Once the Basket and Fry Tray are properly placed in the Main Unit Housing, the Control Panel will be illuminated. Pressing the Power Button once will set the appliance to a default cooking temperature. Pressing the Power Button a second time will start the cooking process. Pressing the Power Button during the cooking cycle will turn the appliance off.

2. Cooking Presets

Press the cooking preset buttons to choose from up to eight cooking presets. See the Preset Chart below for the cooking times and temperatures associated with each preset.

NOTE: The running lights on the Control Panel will illuminate when the cooking cycle begins and will stay illuminated for up to 20 seconds after the cooking cycle is complete.

3. Temperature Control Buttons

The + and – symbols enable you to increase or decrease cooking temperature 5° C at a time. Keeping a button held down will rapidly change the temperature. Temperature control range: 80°C–200°C).

4. Timer Control Buttons

The + and – symbols enable you to increase or decrease cooking time 1 minute. at a time. Keeping the Button held down will rapidly change the time. Time control range: 1– 60 minutes.

5. Time and Temperature Display

This display will keep track of the temperature and remaining cooking time.

Preset Chart

Once you are familiar with the appliance, you may want to experiment with your own recipes. Simply choose the time and temperature that suits your personal taste.

Function	Default cooking time	Default cooking temperature	Adjustable time range	Adjustable temperature range
Chips	20 mins	200°C	1-60 mins	80°C-200°C
Drumstick	25 mins	180°C	1-60 mins	80°C-200°C
Shrimp	20 mins	160°C	1-60 mins	80°C-200°C
Cake	25 mins	160°C	1-60 mins	80°C-200°C
Beef steak	20 mins	160°C	1-60 mins	80°C-200°C
Fish	20 mins	180°C	1-60 mins	80°C-200°C
Rib	15 mins	180°C	1-60 mins	80°C-200°C
Keep Warm	120 mins	90°C	1-120 mins	60°C-90°C

INSTRUCTIONS FOR USE

Before First Use

1. Remove all the packaging material.
2. Remove any stickers or labels from the appliance.
3. Before initial use, wipe the inside and outside of the appliance with a warm, moist cloth and mild detergent. Hand wash all cooking accessories.
4. Before cooking food, preheat the appliance for a few minutes to allow the appliance to burn off the manufacturer's protective coating of oil. Wipe the appliance with warm, soapy water and a washcloth after this burn-in cycle.
5. Place the appliance on a stable, horizontal, and level surface. Do not place the appliance on a surface that is not heat resistant. Ensure that

the appliance is used in an area with good air circulation and away from hot surfaces and any combustible materials. Do not place on the stove top.

6. Place the Fry Tray in the Basket. Slide the Basket into the appliance. If the Basket is placed properly, it will click into place.

NOTE: This appliance cooks using hot air. Do not fill the Basket with oil or frying fat. Do not put anything on top of the appliance. This disrupts the airflow and affects the cooking results.

Using the Appliance

1. Plug the appliance into a grounded wall socket.
2. To preheat, push the Power Button.
3. Press the Temperature Increase or Decrease Buttons to set the cooking temperature.
4. Press the Time Decrease Button to set the preheat time to 3 minutes. When the preheat cycle finishes, carefully pull the Basket out of the appliance and place the ingredients inside.
NOTE: For better performance, always use the Fry Tray with the Basket.
5. Do not touch the Basket directly because the Basket becomes very hot during operation. Only hold the Basket by its handle.
6. Press the Power Button. Set the appropriate time and temperature for the ingredients you are cooking.

7. When the timer beeps five times, the set cooking time has elapsed. Pull the Basket out of the appliance and place it on a heat-resistant surface.
8. If the food is fully cooked, use tongs to remove food.

CAUTION: Do not turn the Basket upside down because any excess oil that has collected on the bottom of the basket will leak onto the ingredients.

9. If the food is not fully cooked, simply slide the Basket back into the appliance and add a few minutes to the cooking time.
10. The appliance is instantly ready for preparing another batch.

Shaking

To ensure even cooking, some foods require shaking during the cooking process. Remove the Basket from the appliance. Gently shake the contents as needed and place them back in the appliance to continue cooking.

CAUTION: The Basket will be hot. Wear an oven mitt during this procedure.

1. Place the Basket on a heat-resistant surface.
2. Shake the ingredients in the Basket.
3. Return the Basket to the appliance to finish cooking.

Tips

- Foods that are smaller in size usually require a slightly shorter cooking time than larger foods.
- Large quantities of food only require a longer cooking time than smaller quantities.
- Shaking smaller-sized foods halfway through the cooking process ensures that all the pieces are fried evenly.
- Adding a bit of vegetable oil to fresh potatoes is suggested for a crispier result. When adding oil, do so just before cooking and add only a small amount onto the potato.
- Snacks normally cooked in an oven can also be cooked in this appliance.
- Use premade dough to prepare filled snacks quickly and easily. Premade dough also requires a shorter cooking time than homemade dough.
- You can use this appliance to reheat foods. Simply set the temperature and time to however warm you want your food.

TROUBLE SHOOTING

Symptom	Possible Cause	Solution
The appliance does not work	The appliance is not plugged in.	Plug the Power Cable into a wall socket.
	You have not turned the appliance on by setting the preparation time and temperature.	Press the Power Button. Select a time and temperature. Press the Power Button again and cooking will begin.
	You have probably turned off the appliance. If you press the Power Button while the appliance is cooking, you will trigger the Auto Shut-Off mode.	Press the Power Button. Select a time and temperature. Press the Power Button again and cooking will begin.
Food is not cooked	The Basket is overloaded.	Use smaller batches for more even frying.
	The temperature is set too low.	Raise temperature and continue cooking.
Food is not fried evenly	Some foods need to be shaken during the cooking process.	See "Shaking" in the "Instructions for Use" section.
Basket will not slide into appliance properly	The Basket is overloaded.	Do not fill the Basket above the maximum line.
	The Fry Tray is not placed in the Basket correctly.	Gently push the Fry Tray into the Basket until it clicks.
White smoke coming from appliance	Too much oil is being used.	Wipe down to remove excess oil.
	The Basket has grease residue from the previous operation.	Clean the basket after each use.
French fries are not fried evenly	Potatoes are not prepped properly.	Consult a recipe for potato type and prep.
	Fries are not cut evenly.	Cut fries thinner or reshape fries.
	Fries are too crowded.	Spread fries out or cook a smaller batch.
	Potatoes are not rinsed properly during preparation.	Pat dry to remove excess starch.
Fries are not crispy	Raw fries have too much water.	Dry potato sticks properly before misting oil.
		Cut sticks smaller.
		Add a bit more oil.

FREQUENTLY ASKED QUESTIONS

1. **Can I prepare foods other than fried dishes with my appliance?** You can prepare a variety of dishes, including steaks, chops, burgers, and baked goods.
2. **Is the appliance good for making or reheating soups and sauces?** Never cook or reheat liquids in the appliance.
3. **Is it possible to shut off the appliance at any time?** Press the Power Button once or remove the Basket.
4. **What do I do if the appliance shuts off while cooking?** As a safety feature, the appliance has an Auto Shut-Off device that prevents damage from overheating. Remove the Basket and set it on a heat-resistant surface. Allow the appliance to cool down. Remove the Power Cable from the outlet. Once cool, plug the Power Cable back into the socket. Restart by pressing the Power Button.
5. **Does the appliance need time to heat up?** If you are cooking from a cold start, add 3 minutes to the cooking time to compensate.
6. **Can I check the food during the cooking process?** You can remove the Basket at any time while cooking is in progress. During this time, you can shake the contents in the Basket if needed to ensure even cooking.
7. **Is the appliance dishwasher safe?** Only the Fry Tray is dishwasher safe. The appliance itself, which contains the heating coil and electronics, should never be submerged in liquid of any kind or cleaned with anything more than a warm, moist cloth or nonabrasive sponge with a small amount of mild detergent.
8. **What happens if the appliance still does not work after I have tried all the troubleshooting suggestions?** Never attempt a home repair. Contact customer service and follow the procedures set forth by the guarantee. Failure to do so could render your guarantee null and void.

Cleaning

Clean the appliance after each use. The Basket and the Fry Tray are coated with a special nonstick surface. Never use abrasive cleaning materials or utensils on these surfaces.

1. Remove the Power Cable from the wall socket and be certain the appliance is thoroughly cooled before cleaning.
2. Wipe the outside of the appliance with a warm, moist cloth and mild detergent.
3. Clean the Basket and the Fry Tray with hot water, a mild detergent, and a nonabrasive sponge.

NOTE: The Fry Tray is dishwasher safe.

TIP: Should the Fry Tray contain difficult-to-remove food particles, soak in hot, soapy water for 10 minutes.

NOTE: The rubber bumpers on the Fry Tray are part of the Fry Tray and should generally not be removed. However, if the rubber bumpers need to be cleaned, they can be removed and reattached: To remove the rubber bumpers, locate the capped end of the

bumpers and push the capped end off of the Fry Tray. There will be some resistance, but keep pushing until the rubber bumpers come off of the Fry Tray. Take note of the slot on which the bumpers were sitting. To reattach the rubber bumpers, align the hole in the rubber bumpers with the slots from which the rubber bumpers were removed. Slide the rubber bumpers all the way back onto the slot on the Fry Tray.

4. Clean the inside of the appliance with hot water, a mild detergent, and a nonabrasive sponge.
5. If necessary, remove unwanted food residue from the heating element with a soft cleaning brush.

Storage

1. Unplug the appliance and let it cool down thoroughly.
2. Make sure all components are clean and dry.
3. Place the appliance in a clean, dry place.

One Year Warranty Statement

Smith+Nobel offer a 1 year warranty from the date of purchase. Please keep your receipt as proof of purchase for this product warranty. This warranty covers manufacturing defects and abnormal deterioration when the product is used in normal domestic use and in accordance with the care and use instructions provided. It does not cover normal wear and tear, negligence or misuse of the product. Should you have to make a claim under this warranty please cease using the product and return it to your nearest Harris Scarfe store at your expense with your proof of purchase. The store will arrange for the product to be assessed. This assessment may be completed in-store or may involve sending the product to an external assessor. If the product is deemed to have a manufacturing defect or abnormal deterioration the item will be replaced or refunded.

This warranty is provided in addition to any other rights and remedies you may have under the Australian Consumer Law.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

DS Opco Pty Ltd

Level 4, 111 Cecil Street, South Melbourne, Victoria 3205, Australia

Ph: 1300 304 505 Email: customerservice@harrisscarfe.com.au