

smith+nobel 



## **16L Multi-Function Digital Air Fryer**

Model No.: TM-AF700D

### **Instruction Manual**

Read this instruction manual carefully  
before use and keep for future reference.

# Important Safeguards

**When using this electrical appliance, the following basic safety precautions should always be followed:**

## For Your Safety

- **Voltage:** Make sure your outlet voltage and circuit frequency correspond to the voltage stated on the appliance rating label. If it does not match, contact our after sales support line and do not use the appliance.
- **Connection:** Insert the plug properly into an earthed mains socket. Make sure the socket is within easy reach so the plug can easily be removed if necessary.
- **Electrical circuit:** To avoid an electrical circuit overload do not use a high wattage appliance on the same circuit with the Air Fryer.
- **Do not immerse:** To protect against electric shock, do not immerse the cord, plug or the electric base in water or other liquid. If the base is accidentally immersed, immediately unplug the power plug, dry the appliance and have it checked by qualified service personnel.
- **Protect from moisture:** Do not expose the electrical connections to water. Do not use the appliance, or touch the plug, with wet or damp hands, on a damp floor or when the electric base is wet.
- **Power cord:** A short power supply cord is provided to reduce the hazards resulting from becoming entangled in or tripping over a longer cord. However, if an extension cord must be used, make sure its marked electrical rating is the same as the product. Arrange the extended cord so it will not drape over the table or benchtop where it can be pulled on or tripped over accidentally. Do not kink, bend, squash, strain or damage the power cord and protect it from sharp edges and heat. Do not let the cord hang over the edge of a table or benchtop, or touch hot surfaces.
- **Damage:** Check the power cord regularly for visible damage. If it is damaged, it must be replaced by the manufacturer, its authorised service centres or similarly qualified personnel in order to avoid any hazards. Do not pick up or operate an appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

In case of damage, call our after sales support line for advice on repair or return of the damaged product.

- **Unattended:** Do not leave the appliance unattended when plugged in.
- **After use:** Unplug the appliance after use. Wait until it has cooled completely before attempting to move or clean it.
- **Disconnect:** Always unplug the power cord when the appliance is not in use. When unplugging the appliance, grip by the plug, do not pull by the cord.
- **RCD:** Unless your home is already fitted with a residual current device (safety switch), we recommend installing an RCD with a rated residual operating current not exceeding 30mA to provide additional safety protection when using electrical appliances. See your electrician for professional advice.

## Caution: Hot Surfaces!

- The Air Fryer and accessories will become very hot during use. Do not come into contact with heated parts while or after using the Air Fryer! Only touch the handles and control knobs while the Air Fryer is in operation or immediately after it has been switched off. The appliance needs approximately 30 minutes to cool down. Wait until the Air Fryer has cooled down fully before it is transported, cleaned or stored away. Use oven gloves and the rotisserie removal tool if necessary when handling the hot accessories.
- **Open the door!** Take care when opening the door! There is a danger of scalding from hot steam.
- **Free space:** Do not place the appliance against a wall or against other appliances. Hot air up to 160 Degrees expels through the rear vent of the appliance. Leave at least 10cm clearance around the entire appliance, including directly above it. Additional care should be taken when placing appliances on bench top surfaces or near splash backs where such materials (Acrylics, timber etc.) do not have the high heat resistant properties, so advised to place them on top of a heat resistant material between bench and appliance and further away from wall surfaces / splash backs.
- **Safe distance:** During hot air frying, hot steam is released through the air outlet openings. Keep your hands and face at a safe distance from the steam and from the air outlet openings.

# Usage Conditions and Restrictions

- **Indoor domestic use only:** This appliance is intended for indoor domestic use only. Do not use it outdoors.
- **Intended purpose:** This Air Fryer works with hot air and is not a conventional fryer that is filled with oil or deep-frying fat. It is suitable for frying, baking, grilling, dehydrating, keeping warm or de-frosting food. It generally works like a convection fan oven. It is not intended for use with any non-food materials or products. Do not use the appliance for anything other than its intended purpose, and only use it as described in this manual. Any other use may cause fire, electric shock or injury.
- **Accessories:** Do not use accessories not supplied with this product. Improper use or installation may result in the risk of fire, electric shock or injury.
- **Usage restrictions:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- **Children:** Supervise children to ensure they do not play with the appliance. Close supervision is necessary when any appliance is used by or near children.
- **Location:** To ensure efficient operation and avoid overturning, always place the appliance on a level and stable work surface.
- **Protect from heat:** Do not place the appliance on or near a hot gas or electric burner, or near a heated oven.
- Do not pour any liquids (e.g. oil or water) directly into the Air Fryer or the rotating mesh basket or place a liquid filled vessel into the Air Fryer. It works exclusively with hot air.
- **CAUTION:** Never use the open door as a deposit surface, e.g. for the rotating basket! Hot accessories could damage the door. In addition, the Air Fryer could tip over and present a risk of injury.
- **CAUTION:** The Air Fryer must always be disconnected from the mains power when it is left unattended and before transporting, assembling, disassembling and cleaning the Air Fryer.
- **WARNING:** Do not make any modifications to the Air Fryer. Also do not replace the connecting cable yourself. If the Air Fryer, the connecting cable or the accessories of the Air Fryer are damaged, they must be replaced by the manufacturer, customer service department or a specialist workshop in order to avoid any hazards.
- **CAUTION:** The Air Fryer is not designed to be operated with an external timer or a separate remote control system.
- **CAUTION:** Note the cleaning instructions in the "Care and Cleaning" chapter!
- **Liability:** We accept no liability for any damages or injury caused by improper use, incorrect handling or noncompliance with these instructions.
- **Plastic bags and films:** Keep children and animals away from plastic bags and films. There is a danger of suffocation.
- **Check the Air Fryer:** Always check the Air Fryer for damage before putting it into operation. The Air Fryer should only be used when it is fully assembled, undamaged, and in working order!
- **Place the Air Fryer:** Always place the Air Fryer on a dry, even, firm and heat resistant surface. Never place the Air Fryer on a soft surface. Do not cover the air inlet or the air outlet when the appliance is working. Otherwise it could overheat and be damaged. Do not place the Air Fryer on or next to heat sources such as hobs or ovens. Keep naked flames, e.g. burning candles, away from the Air Fryer and the connecting cable. Do not expose the Air Fryer to extreme temperatures, persistent moisture, direct sun-light or impacts. Keep the Air Fryer in a dry place at temperatures of between 0 and 40°C.
- **Objects:** Never place objects on the Air Fryer.
- **Parts from the manufacturer:** Use only original spare parts from the manufacturer. If accessory parts which are not authorised by the manufacturer are used, all warranty and guarantee claims are void.
- **WARNING:** Do not use the Air Fryer if it has malfunctioned, fallen or been dropped in water. Have it checked in a specialist workshop before using it again.

- **WARNING:** Forks, Skewers and other metal parts with this unit are sharp and will get extremely hot during use. Great care should be taken to avoid personal injury. Wear protective oven mitts or gloves.

## Warning


- Do not use the Air Fryer in rooms containing easily ignitable or explosive substances.
- Do not operate the Air Fryer in the vicinity of combustible material. Do not place any combustible materials (e.g. cardboard, paper or plastic) on or in the Air Fryer.
- Do not connect the Air Fryer along with other consumer appliances (with a high wattage) to a multiple outlet power board or adaptors in order to prevent overloading and a possible short circuit (fire).
- Do not insert anything into the ventilation openings of the Air Fryer and make sure that these do not become clogged.
- Make sure that foodstuffs containing oil and fats are not overheated. Do not place any vessels filled with oil or other liquids into the Air Fryer.
- Do not cover the Air Fryer during operation in order to prevent it from catching fire.
- In the event of a fire: Do not extinguish with water! Smother the flames with a fire blanket or a suitable fire extinguisher.










## Save These Instructions

**THIS APPLIANCE IS DESIGNED FOR HOUSEHOLD USE ONLY**



# Features Of Your Digital Air Fryer







**A****B1****B2****B3****B4****C1****C2****E****D**

## Main Unit

(See page 5 for illustrations)

- 1 Main Unit (1x)
- 2 Rotating Mesh Basket (1x)
- 3 Rotating Rotisserie Fork with Locking Screws (2x)
- 4 Shafts (of the rotating rotisserie fork or rotating rotisserie skewers) (2x)
- 5 Rotisserie Removal Tool (1x)
- 6 Rack Wheels with Locking Screws (for Rotating Rotisserie Skewers) (2x)
- 7 Rotating Rotisserie Skewers (10x)
- 8 Oil Drip Tray (1x)
- 9 Air Flow Racks (3x)
- 10 START/STOP Button (START/STOP Button for Setting the Temperature & Time)
- 11 Interior Light (not shown)
- 12 Support for the Shaft & Rotating Mesh Basket (right)
- 13 Rails
- 14 Removable inner glass assembly
- 15 Door
- 16 Cooking Space
- 17 Holder for the Shaft & Rotating Mesh Basket (left)
- 18 Heating Element (not shown)
- 19 Control Panel
- 20 Air Inlet Slots
- 21 Air Outlet Openings

## Control Panel

- 22 LED Display (alternating display of temperature & remaining cooking time during operation)
- 23 Operating Lamps (lighting up successively: Air Fryer is in operation; flashing: operation has been interrupted)
- 24 10 Programs
- 25  Switch the Light in the Air Fryer On/Off
- 26  Switch Rotating Function (for Rotating Mesh Basket, Rotating Rotisserie Spit) On/Off
- 27  Set the Cooking Temperature : press briefly and the temperature can be set with the START/STOP Button
- 28  Set the Cooking Time: press briefly, then set the cooking time with the START/STOP Button

## Intended Use

- This Air Fryer works with hot air and is not a conventional fryer that is filled with oil or deep-frying fat. It is suitable for frying, baking, grilling, dehydrating, keeping warm or defrosting food. It generally works like a convection fan oven.
- The Air Fryer is for personal domestic use only and is not intended for commercial applications.
- The Air Fryer should only be used as described in these instructions. Any other use is deemed to be improper. Incorrect operation and incorrect handling may cause faults with the Air Fryer and cause injury to the user.
- The following are excluded from the warranty: all defects caused by improper handling, damage or unauthorised attempts at repair. The same applies to normal wear and tear.

## Before Initial Use

- Check the items supplied for completeness (See page 5-6) and possible transport damage. If you find any damage, do not use the Air Fryer (!), but rather contact the customer service department.
- Remove any possible films, stickers or transport protection from the Air Fryer. Never remove the rating plate and any possible warnings!
- The Air Fryer should be used for the first time without any food in it as it may produce some smoke or odours due to coating residues. Allow the Air Fryer to heat up on the highest temperature setting for approx. 15 minutes without any food in it (see the "Using the Air Fryer" chapter).
- Thoroughly rinse all accessories. Follow the instructions in the "Care and Cleaning" chapter to do this.

# Using the Accessories

(See page 5-6 for illustrations)

## Oil Drip Tray

The oil drip tray (8) should always be inserted so that any dripping fat, crumbs or other food residues can be collected in it. Slide the tray right into the bottom of the cooking space (16) or onto the bottom rails.

## Air Flow Racks

The air flow racks (9) are intended for dehydrating. However, they can also be used for crisping, warming up etc.

The air flow racks are slid onto the rails (13) in the cooking space (16) (see Illustration A). The heating element (18) is located at the top of the cooking space, so the higher up a baking rack is placed, the more intense the heat is from above.

In the top section, the food is cooked faster and crispier. The middle position should be chosen to achieve even heating from all sides. The bottom rails are suitable for gentle cooking.

## Rotating Rotisserie Skewers

Pieces of meat, fish, vegetables etc. are placed on the skewers (7) and grilled in the Air Fryer. The skewers can either be placed on the air flow racks (9) or inserted into the associated rack. In the rack, they are turned during grilling.

Assemble the rack for skewers and insert into the Air Fryer:

### **NOTE** ⚠

**The shaft (4) contains two small round notches. They mark the outermost position of the locking screws. These must not be attached any further than the outer ends of the shaft to ensure that smooth operation is possible.**

**Be careful when handling the skewers in order to prevent any injuries!**

**The rack and skewers will be hot and oven gloves must be used when handling.**

- Slide the rack wheel (6) with the L marking onto the left-hand end of the shaft with just one notch (see Illustration B1). The locking screw of the rack wheel is directed outwards.
- Fix the rack wheel gently with the locking screw. The shaft contains a small round notch for the tip of the locking screw. Do not tighten it too much so that the rack wheel can be moved if necessary after attaching the skewers.
- Mount the second rack wheel on the shaft in the same way (see Illustration B1).
- Place the tip of a skewer (with food on it) through the round hole in the left-hand rack wheel (see Illustration B2).
- Press together the other end (the clip) of the skewer slightly, slide it into the opposite notch in the right-hand rack wheel and allow it to engage (see Illustration B2).
- Fit the rest of the skewers in the same way so that they are distributed evenly in the rack (see Illustration B2).
- Tighten the locking screws of the rack wheels.
- Plug the left-hand end of the shaft as far as it will go into the round holder on the left-hand side of the cooking space (16) (see Illustration B3). Then hang the other end of the shaft into the support on the right-hand side of the cooking space (see Illustration B4).
- Check that it fits securely. The rack must not be able to rotate about its own axis while the Air Fryer is switched off. If this is not the case, plug the left-hand end of the shaft deeper into the holder.

After use, remove the rack from the cooking space using the rotisserie removal tool (5) (see the "Rotisserie Removal Tool" section). To remove the skewers from the rack, press together the clips. It is essential that you use oven gloves to do this!

## Rotating Rotisserie Fork

The rotating rotisserie fork consists of the shaft (4) and two rotating forks (3). It is suitable for grilling large pieces of meat, e.g. chicken, grilled or roast pork.

Assemble the rotating rotisserie fork and insert it into the Air Fryer:

### NOTE

**The shaft (4) contains two small round notches. They mark the outermost position of the locking screws. These must not be attached any further than the outer ends of the shaft to ensure that smooth operation is possible.**

**Be careful when handling the fork in order to prevent any injuries!**

**The fork will be hot and oven gloves must be used when handling.**

- Slide one of the rotating forks onto the shaft and lock it with the locking screw. The shaft contains a small round notch for the tip of the locking screw. In the case of smaller pieces of food, the rotating forks can be secured more centrally on the shaft.
- Slide the items you want to grill onto the rotating fork.
- Slide the other rotating fork onto the shaft and lock it with the locking screw.
- Plug the left-hand end of the shaft with just one notch (see Illustration C1) as far as it will go into the round holder on the left-hand side of the cooking space (16). Then hang the other end of the shaft into the support on the right-hand side of the cooking space.
- Check that it fits securely. The rotating rotisserie fork must not be able to rotate about its own axis while the Air Fryer is switched off. If this is not the case, plug the left-hand end of the shaft deeper into the holder.

After use, remove the hot rotating rotisserie fork from the cooking space using the rotisserie removal tool (5) (see the "Rotisserie Removal Tool" section).

Always use oven gloves to remove the rotating forks and take off the grilled items.

## Rotating Mesh Basket

In the rotating mesh basket (2), the food is rotated during cooking so that it becomes crispy on all sides. The rotating mesh basket is particularly suitable for preparing chips or other potato products, small pieces of vegetables and meat as well as frozen products, e.g. chicken nuggets or squid rings.

Fill the rotating mesh basket and insert it into the Air Fryer:

- Open the flap of the rotating mesh basket (see Illustration D).
- Fill the rotating mesh basket no more than  $\frac{3}{4}$  full with food. It should not be too full to ensure that the food is cooked evenly.
- Close the flap and ensure that it is shut correctly so that it does not open during use.
- First insert the left-hand side with the L marking of the rotating mesh basket into the cooking space (16) (see Illustration C1). To do this, plug the left end (with just one notch) of the shaft as far as it will go into the round holder on the left-hand side of the cooking space. Then hang the other end (with two notches) of the shaft into the support on the right-hand side of the cooking space.
- Check that it fits securely. The rotating mesh basket must not be able to rotate about its own axis when the Air Fryer is switched off. If this is not the case, plug the left-hand end of the shaft deeper into the holder.

After use, remove the hot rotating mesh basket from the cooking space using the rotisserie removal tool (see the "Rotisserie Removal Tool" section). Always use oven gloves to open and empty the rotating mesh basket.

## Rotisserie Removal Tool

The rotating mesh basket, rotating rotisserie fork or the rack containing skewers is taken out of the cooking space using the removal tool (5).

- Place the ends of the rotisserie removal tool under the shaft (see Illustration E).
- First lift up the right-hand side of the shaft and move it forwards a little until the left end of the shaft is released from the holder.
- Carefully lift the rotating mesh basket, rotating rotisserie fork or the rack out of the cooking space (16) and place down on a heat-resistant surface.

# Using the Air Fryer

## **NOTE**

**CAUTION – Danger of burns! All inserts will become extremely hot in the Air Fryer. It is essential to use oven gloves to remove them. Use the rotisserie removal tool for the rotating mesh basket, rotating spit and the rack for skewers.**


**Do not place food that is still packed in plastic wrap or plastic bags in the Air Fryer.**

**Only ever place down the hot accessories on a heat-resistant surface.**

**Make sure that the food that you would like to prepare does not come into contact with the heating element of the Air Fryer.**

## Manual setting:

Touch the  button (27) briefly and then adjust the START / STOP button (10) to set the temperature to 65 °C To 200 °C (dehydration: 45-85 °C).











Touch the  button (28) briefly and use the START / STOP button (10) to choose the cooking time from 1min to 60min (Dehydrate: 0.5-24h).

The door (15) of the Air Fryer must be closed for settings to be made and buttons to be pressed.



- Completely unwind the mains cable and plug the mains plug into a plug socket.
- Open the door (15). If the oil drip tray (8) is not to be used as a baking tray, slide it into the bottom of the cooking space (16).
- Select a suitable accessory for the food that is to be prepared (see the "Using the Accessories" chapter).
- Process the food and place it on / in the accessory. Attach this accessory in the Air Fryer (see the "Using the Accessories" chapter).
- Close the door.
- Press the START/STOP button (10). The displays on the control panel (19) switch on.
- Either set the temperature and cooking time manually or select one of the 10 programmes.



## Choose a programme:


Touch the required programme symbol (24). When it flashes, the programme is activated. When the symbol is touched again, the selection is cancelled. The symbols represent the following presets:

Symbol	Programme	Temperature	Cooking time
	FRIES	200°C	20 min
	FISH	200°C	15 min
	SHRIMP	200°C	15 min
	STEAK / CUTLET	200°C	20 min
	CHICKEN	200°C	30 min
	PIZZA	170°C	20 min
	BAKING	160°C	25min
	DEHYDRATE	70°C	8 h (0.5 – 24 h)
	To dry food is the best and effective way to store food. The dehydrate function ensures that it reduces the loss of food nutrients to maintain healthy foods. Dehydrate fruit and vegetables that are in season and store to enjoy throughout the year.		
	TOAST	160°C	20 min
	ROTISSERIE (with automatic rotating function)	200°C	35min

The temperatures and cooking times which are set for the programmes are merely averages and should be adjusted if necessary. As the ingredients differ due to their origin, size, shape, quality and brand, the actual cooking temperatures and times may vary.

To change the temperature or cooking time of a selected programme, touch the  or  button as you would for manual setting and use the START / STOP button (10) to set a value.

- Press the START/STOP button to switch on the Air Fryer. Successively illuminating operating lamps (23) indicate that the Air Fryer is operating. If operation is interrupted, they flash.
- If the rotating mesh basket, rotating spit or the rack for skewers is used, touch the  button (26) to start the rotating function. Touching the  button again will stop the rotating function.

Until you are properly familiar with the Air Fryer, the condition of the food should be checked in between times to ensure that it does not burn. To do this, switch on the light using the  button (25) or open the door. When the door is opened, operation is interrupted automatically and the light switches on. Operation is resumed once the door is closed.

- Once the cooking time has elapsed, the Air Fryer switches off automatically and a beep is heard. If the Air Fryer is to be stopped prematurely, press the START/STOP button. To switch off the Air Fryer entirely, hold down the START/STOP button until the "OFF" displays on the control panel, the heating-up will stop immediately, and the fan will automatically shut down after approximately 20 seconds.
- Carefully open the door and take the cooked items out of the Air Fryer. Only ever take out the rotating mesh basket, rotating spit or the rack for skewers using the rotisserie removal tool (5).
- Remove the mains plug from the plug socket after use.
- Allow the used accessories and Air Fryer to cool down and then clean them (see the "Care and Cleaning" chapter).

## Automatic Switch-off

The appliance has a built in timer, it will automatically shut down the appliance when the count down is completed and a beep is heard. If the Air Fryer is to be stopped prematurely, press the START/STOP button. To switch off the Air Fryer entirely, hold down the START/STOP button until the "OFF" displays on the control panel, the heating-up will stop immediately, and the fan will automatically shut down after approximately 20 seconds.

## Memory function

This Air Fryer has memory function, if you do not press the START/STOP button to stop the operation before opening the door or unplugging the plug, the machine will automatically continue the current cooking process once the door is closed again or the machine is turned on again.

### NOTE

**You may open the Air Fryer door to view the rotisserie at any time during the process to check the progress. The appliance will stop working when the door is opened. It will resume cooking and the remaining time showing on the display after the door is closed.**

## Tips:

- Generally it is not necessary to preheat the Air Fryer. When preparing food which is to be ready "on the dot", it is advisable to extend the cooking time by 3 minutes.
- Cooking times are dependent on the size and quantity of the food and on the cooking temperature. However, in general the cooking times are shorter than in a conventional oven. Start with shorter cooking times and then adapt the cooking times to your personal taste.
- Generally no oil is required for preparing food. You can add oil to your food to enhance the taste by spraying your food with a little oil from the oil atomiser (not included).
- When preparing mass-produced frozen products, you should follow the times and temperatures specified by the manufacturer. Before the specified cooking time elapses, check whether the food is already cooked through because the cooking time can be slightly shorter than in a conventional oven.



# Care and Cleaning

## **NOTE** ⚠

**Pull the mains plug out of the plug socket and allow the Air Fryer and accessories to cool down before doing any cleaning.**  
**Surfaces could be damaged! Do not use any corrosive or abrasive cleaning agents or scouring sponges to clean the Air Fryer.**

## **NOTE** ⚠

**The construction of the door assembly (15) allows for the removal of the internal Window pane (14) to facilitate cleaning to ensure a clear view of the cooking chamber.**  
**The internal Window pane can be removed by opening the door, grasping the raised rim of the window pane and sliding it out of the recess.**  
**After cleaning, the window pane must be slid back in the door recess, you will hear a click when it is locked into correct position.**  
**DO NOT operate the appliance at any time without this window pane in place.**

## **WARNING** ⚠

**Do Not try to operate the unit without the inner glass assembly fixing back.**

Clean the main unit (1) and the used accessories immediately after each use. Do not allow food residues to dry on.

- Do not immerse the main unit and door in water or other liquids! Do not place them in the dishwasher! Clean them with a damp cloth and, if necessary, a little detergent.
- Rinse all other used parts with detergent and warm water or in the dishwasher. In the case of stubborn dirt, we recommend soaking the accessories in warm water and detergent beforehand.
- Allow all parts to dry completely or dry them with a tea towel.

## **WARNING** ⚠

**Electric Shock Hazard!**  
**Disconnect the power before cleaning the appliance.**

**Do not immerse the cord, plug or electric base in any liquid.**

**Failure to follow these instructions can result in death or electric shock.**

## Storage

- Before packing the Air Fryer away for storage, ensure it is unplugged from the power supply and has completely cooled down, is clean and dry.
- We recommend storing all parts of the appliance in the original carton, which will protect it from dust.
- Store the Air Fryer in a clean and dry place, out of children's reach.
- Do not wrap the cord around the appliance during storage.
- The unit has no user-serviceable parts contained within. Do not attempt to repair, disassemble or modify the appliance. If the appliance requires repair or service, contact our after sales support centre for advice.

## **IMPORTANT!**

**Trying to repair the appliance yourself, undertaking incorrect repairs or making modifications will expose you to considerable danger and will void the warranty.**

## Technical Specifications

Rated power input: 1800W  
Voltage and frequency: 220-240V AC, 50Hz  
Temperature settings: 65-200°C  
(Dehydrate: 45-85°C)  
Time settings: 1-60min (Dehydrate: 0.5-24h)

**NOTE: As a result of continual improvements, the design and specifications of the product within may differ slightly to the unit illustrated on the packaging.**

# FAQs and Troubleshooting Guide

**NOTE** ⚠ **Do not attempt to repair an electrical appliance yourself!**

If the Air Fryer does not work properly, first check whether you are able to rectify the problem yourself. If the problem cannot be solved with the following steps, contact the customer service department.

Problem	Possible Cause	Solution
The Air Fryer does not work. The displays on the control panel do not switch on.	The mains plug is not inserted correctly in the plug socket.	Push the mains plug into the plug socket as far as it will go.
	The plug socket is defective.	Try another plug socket.
	No mains voltage is present.	Check the fuse of the electrical distributor (fuse box).
	The overheating protection has been triggered.	Pull the mains plug out of the plug socket and allow the Air Fryer to cool down completely. Then try again. If the Air Fryer still cannot be switched on, contact the customer service department.
The fuse in the electrical distributor (fuse box) is triggered.	Too many appliances connected to the same circuit.	Reduce the number of appliances in the circuit.
The food has not been cooked evenly.	Different items of food with different cooking times have been prepared at the same time.	Place food with a longer cooking time in the Air Fryer first, then add ingredients with a shorter cooking time later.
	Items of food which require different cooking temperatures have been prepared at the same time.	Prepare items of food with different cooking temperatures one after the other.
The food has not been cooked evenly.	The set cooking time was too short or the temperature too low.	Increase the cooking time or temperature.
	The rotating mesh basket or baking	Reduce the amount of food.
	The items of food are piled on top of one another.	Spread the food and mix it
The food is slightly burnt.	The selected temperature is too high or the cooking time too long.	Reduce the temperature or cooking time.
Chips made from fresh potatoes are not crispy.	The potatoes contain too much water.	Cut the potatoes into narrower pieces. Dab the potato pieces dry with some kitchen towel and then trickle a little cooking oil over them.
During use, an unpleasant smell is detected.	The Air Fryer is dirty.	Follow the instructions in the "Care and Cleaning" chapter.
	The Air Fryer is being used for the first time.	A smell often develops when new appliances are first used. The smell should disappear once the appliance has been used several times.

# Recipes

## NOTE

**Before you start preparing any food, it is essential to read the "Using the Accessories" and "Using the Air Fryer" chapters to familiarise yourself with the way that the Air Fryer works. This knowledge will then enable you to prepare lots of different dishes following any recipes you want.**


The temperatures and cooking times specified in the following suggested recipes are guideline figures. As the ingredients differ due to their origin, size, shape and quality, the settings actually required may vary. It is important to check how the food is cooking from time to time and adjust the temperature or cooking time.

## Apple Turnovers

### Ingredients:

2 Apples  
1 roll Puff pastry  
50g Brown sugar  
2 tbsp. Flour  
2 tbsp. Lemon juice  
To taste Cinnamon

### Method:


- Peel the apples, remove the cores and cut them into small pieces.
- Mix together the pieces of apple, flour, sugar and lemon juice and add cinnamon to taste.
- Roll out the puff pastry and divide it into pastry squares with an edge approx. 10 cm long.
- Spread one tablespoon of the filling onto the pastry squares.
- Brush a little water onto the edge of the pastry and fold it up into triangles. Firmly press down the edge of the pastry.
- Spread the apple turnovers on the air flow racks.
- Insert the air flow racks into the Air Fryer in the middle position.
- Start the  "Baking" programme.
- Before the cooking time elapses, check whether the apple turnovers are golden brown and take them out before the end of the cooking time if necessary. If the apple turnovers appear too light, extend the cooking time.

## Banana Chips

### Ingredients:

To taste Bananas

### Method:


- Peel the bananas and cut them into slices 3 mm thick. The thinner they are, the faster they will dry.
- Spread the banana slices on the air flow racks.
- Insert the air flow racks into the Air Fryer.
- Start the  "Dehydrate" programme and set the cooking time to 6 hours.
- Check from time to time whether the banana slices are dry. It has a toughened texture when dehydrated, but does not feel hard when they are done.

## Crumbed Chicken Breast

### Ingredients:

2 Chicken breast fillets  
2 Egg whites  
½ cup Flour for breadcrumbs  
½ cup Breadcrumbs  
1 tsp. Salt  
½ tsp. Pepper

### Method:

- Separate off the egg white.
- Place the egg white, flour and breadcrumbs in three separate bowls.
- Chop each of the chicken breast fillets into strips of equal sizes.
- Season the chicken breast fillet strips with salt and pepper, roll in the flour, then dip them in egg white and roll in the breadcrumb coating.
- Place the chicken breast fillet strips on the air flow racks.
- Insert the air flow racks into the Air Fryer.
- Start the  "Chicken" programme.
- Check in between times whether the chicken breast strips are cooked through and reduce or extend the cooking time if necessary.

## Crumbed Prawns

### Ingredients:

10 Large prawns (peeled and cleaned)

For the breadcrumb coating:

½ cup Flour

½ cup Breadcrumbs

2 Egg whites

### Method:

- Mix the ingredients together.
- Pour the flour into a separate bowl.
- Separate off the egg white and pour it into another separate bowl.
- First roll the prawns in the flour, then dunk them in the egg white and then roll them in the breadcrumb coating.
- Spread the prawns on the air flow racks.
- Insert the air flow racks into the Air Fryer.
- Start the  "Shrimp" programme.
- The prawns are ready for serving when they have developed a lovely golden brown colour. If the prawns are not yet cooked after the set time has elapsed, extend the cooking time.

## Chips


### Ingredients:


4 large Potatoes

1 – 2 tbsp. Cooking oil

To taste Salt

### Method:

- Peel the potatoes and cut them into sticks of equal size.
- Thoroughly wash the potatoes and then dry them off.
- Add 1 – 2 tbsp. of oil to the potatoes and mix in. It is not essential to add oil. However, adding oil will make the chips crispier and give them a more intense flavour.
- Place the sliced potato chips into the rotating mesh basket.
- Insert the rotating mesh basket into the cooking space.
- Start the  "Fries" programme.

- Press the  button to activate the rotating function.
- The chips are cooked when they are golden brown. Reduce the temperature if necessary if the chips start to get too dark. If they are not cooked after the end of the programme, extend the cooking time and adjust the temperature if necessary.

### Tips:


- Depending on how thick you cut your potatoes, you can vary between potato wedges and thick or thin chips. The thicker the potatoes are cut, the longer the cooking time.
- Use waxy potatoes. Young potatoes contain more water and therefore take longer to cook and it is possible that they may not go as crispy.
- Wash the chopped-up potatoes with cold, clear water to remove any excess starch in the potatoes. IMPORTANT: Then thoroughly dry the potatoes. The less moisture is present, the crispier the chips will become.
- Preboiled potatoes will cook more evenly! Cut the potatoes into small sticks and preboil them for around five minutes. This will prevent the chips from being crispy on the outside but not fully cooked on the inside.
- If you are going to prepare frozen chips or other frozen convenience products, follow the manufacturer's specifications on the packaging.

## Flat Head Fillet with Garlic Herb Crust

### Ingredients:

100g Flat head fillet  
2 Egg whites  
2 Garlic cloves  
1 tbsp. Chopped basil  
1 tsp. Paprika powder  
To taste Sea salt, pepper  
½ cup Breadcrumbs

### Method:

- Peel the garlic and squeeze through a garlic press.
- Mix together the garlic, the rest of the herbs and breadcrumbs in a bowl.
- Separate off the egg white and pour it into a separate bowl.
- Dip the flat head fillet in egg white and then coat it in the garlic and herb breadcrumb coating.
- Place the flat head fillet on the air flow racks.
- Insert the air flow racks into the Air Fryer.
- Start the  "Fish" programme.
- If the flat head fillet is not yet cooked, extend the cooking time if necessary.

## Juicy Pork Cutlet

### Ingredients:

4 Pork cutlet(s)  
1 tbsp. Butter  
2 Onion(s), cut into rings  
3 tbsp. Sugar, brown  
1 tsp. heaped Salt  
1 tsp. level Pepper  
2 tbsp. Vinegar  
2 tbsp. Lemon juice  
To taste Ground chilli flakes  
1 pinch Cayenne pepper  
2 tsp. Mustard  
1 tsp. Paprika powder, smoked  
1 1/2 cups Tomato sauce  
1 tbsp. Worcester sauce  
1 cup Water

### Method:


- Place the cutlets on the air flow racks (oil drip tray).
- Mix together the lemon juice, vinegar, salt and pepper.
- Melt the butter in a small pan and fry off the onions in it.
- Add the sugar, allow it to caramelise a little and deglaze with the lemon juice mixture.
- Bring to the boil and pour over the cutlets.
- Stir together the tomato sauce with the water and the Worcester sauce. Mix together the rest of the spices thoroughly with the whisk.
- Pour this sauce over the cutlets.
- Slide the air flow racks onto the middle rail in the cooking space.
- Start the  "Steak/Cutlet" programme.
- If the cutlets are not covered by the sauce, pour the sauce over them from time to time.
- Check how cooked the food is shortly before the end of the programme. Extend the cooking time if necessary.

## Muffins Recipe to Make 10 Muffins

### Ingredients:

70g Butter  
170g Flour  
1 pack Vanilla sugar  
0.5 pack Baking powder  
3 Eggs  
120g Sugar  
120ml Milk  
10 Muffin moulds

### Method:


- Beat the eggs to a froth in a bowl. Gradually add the sugar with the vanilla sugar. Add the butter cut into flakes. Whisk to a good froth until you can no longer see any butter flakes.
- Stir in the milk alternately with the flour and the baking powder.
- Pour the mixture into each of the muffin moulds up to half full.
- Spread the muffin moulds on the air flow racks.
- Insert the air flow racks into the Air Fryer in the middle / bottom position.
- Start the  "Baking" programme.
- Before the cooking time elapses, check whether the muffins are cooked and take them out before the end of the cooking time if necessary.

## Pepperoni Pizza

### Ingredients:

1 Pizza dough, thin crust  
3 tbsp. Pizza sauce  
3/4 cup Mozzarella, shredded  
12 slices Pepperoni

### Method:

- Roll the pizza dough onto an air flow rack.
- Insert the air flow rack into the Air Fryer.
- Start the  "Pizza" programme, set the cooking time to 10 minutes. Flip the dough after 5 minutes.
- Remove the crust from the Air Fryer.
- Top the crust with the sauce, cheese and pepperoni.
- Place the crust back into the Air Fryer. Continue the "Pizza" programme, set the cooking time to 5 minutes.
- Let the pizza cool for 5 minutes before cutting.

## Skewered Chicken

Resting time: approx. 1 day

### Ingredients:

1 large plump chicken breast  
1 pinch Salt  
1 pinch Pepper, white, ground  
1 pinch Thyme, crushed  
2 apples, tart  
1 Medium onion, cut into quarters  
1 clove Garlic  
50ml Oil  
10g Spice mixture (roast chicken spice)

### Method:


- Mix the spices together and season the chicken with the mixture.
- Place the chopped apples, onions and garlic slices in the chicken.
- Seal up the chicken with string or cooking pins.
- Place the chicken in an appropriate vessel. Massage oil and roast chicken spice into the skin. Marinate in the fridge for roughly 12 to 24 hours.
- Slide the oil drip tray onto the bottom rail in the Air Fryer.
- Fix the chicken on the rotating rotisserie fork.
- Attach the rotating rotisserie fork in the Air Fryer.
- Start the  "Rotisserie" programme.
- If the chicken is not yet golden brown and crispy after the end of the programme, start the programme again.  
The grilled chicken tastes delicious with chunks of bread.

## Spiced Chicken Legs

### Ingredients:

5 Chicken legs  
3 tbsp. Olive oil  
2 Garlic cloves  
1 tsp. Sugar  
1 tsp. Chilli powder or paprika powder  
To taste Salt, pepper

### Method:

- Peel the garlic and squeeze through the garlic press.
- Mix the clove of garlic with sugar, chilli/paprika powder, salt, pepper and oil.
- Rub the marinade into the chicken legs and allow it to infuse for at least 20 minutes.
- Place the chicken legs on the air flow racks in the middle position.
- Start the  "Chicken" programme.
- Check how cooked the food is in between times. The cooking time may vary depending on the size of the chicken legs. Adjust the cooking temperature and cooking time accordingly if necessary.



## Super Shaslicks

Resting time: approx. 1 day

### Ingredients:

1 kg lamb neck  
1 Large onion  
1 tsp. Sugar  
1 tbsp. Vinegar  
2 tbsp. Oil  
2 tbsp. Strained tomato(es)  
To taste Salt, black pepper, cayenne pepper

### Method:


- Cut the meat into cubes roughly 2.5 x 2.5 cm in size.
- With the exception of the onion, mix together the rest of the ingredients to make a marinade and mix with the meat.
- Allow it to rest in the fridge for at least 4 hours, ideally overnight. Stir it around a few times.
- Chop the onion into rings.
- Slide the marinated meat and the onion rings onto the skewers.
- Fit the skewers in the rack and insert it into the cooking space.
- Start the  "Steak/Cutlet" programme.
- Press the  button to activate the rotating function.
- Check how cooked the food is in between times. Adjust the cooking temperature and cooking time if necessary.

## S'mores Pizza

### Ingredients:

1/2 cup Heavy cream  
1 & 1/4 cup Chocolate chips  
1 Refrigerated thin crust pizza dough  
9 Graham crackers, crumbled  
1 cup Mini marshmallows  
350g Chocolate candy bar, crumbled  
Chocolate syrup, for serving  
Marshmallow creme, for serving

### Method:

- Bring the heavy cream to a simmer in a saucepan over medium heat to make the ganache.
- Pour the chocolate chips into the saucepan and stir.
- Let the mixture sit for 3 minutes on the heat.
- Whisk until smooth.
- Remove from the heat.
- Shape the pizza dough onto an air flow rack.
- Insert the air flow rack into the Air Fryer.
- Start the  "Pizza" programme.
- Flip the dough after 10 minutes.
- Spread the ganache over the pizza crust.
- Scatter the graham crackers, marshmallows, and chocolate bar over the ganache.
- Place the dough back into the Air Fryer to continue the remaining cooking process until the cooking time elapses.
- Garnish with chocolate syrup and marshmallow creme.



## One Year Warranty Statement

smith + nobel appliances are guaranteed from the date of purchase for 1 year against manufacturing defects and abnormal deterioration when used in accordance with the care and use instructions for normal domestic use. The warranty excludes damage resulting from product misuse or product neglect. Please return at your expense, to a Harris Scarfe store for assessment by a team member. Once approved, a like replacement or refund, may be offered. Please keep your receipt as proof of purchase for this product warranty. The benefits given by this warranty are in addition to other rights and remedies you may have under Australian Consumer law. This warranty is provided in addition to other rights and remedies you may have under law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

**IFI AU Pty Ltd.**

Please contact: **support@ifisource.com** or

call customer service hotline: **+61 1300522523** Mon. - Fri. 9am - 5pm AEST